

Voice Mail Features

During Message Playback

During the playback of the message, any of the following buttons may be pressed:

- "*" Rewind the message by 3 seconds.
- "#" Fast forward the message by 3 seconds.
- "0" Pause the message playback. Press any other button to resume playback.
- "1456789" - Pressing any of these buttons will halt the playback of the message and perform the corresponding action from the post-message playback options.

After Message Playback

After the message has been played back, the system will play a prompt and wait for you to press a button:

- "3" Advanced options. See below for more.
- "5" Replay the current message.
- "6" Go to the next message in the folder.
- "7" Delete or undelete the message.
- "8" Forward the message to another user on the system.
- "9" Save the message to a different folder.
- "*" Replay the menu.
- "#" Exit the voice mail system.

Advanced Options After Listening to a Message

The following buttons may be pressed in the "Advanced Options" menu while you are listening to a message.

- "1" Record a message and send it directly to the mailbox of the person that sent you the current message.
- "2" Call the person that left the message back.
- "3" Play the message envelope.
- "4" Place an outgoing call.
- "5" Leave a message for another user on the system. See Chapter 2 for more information.
- "*" Return to the main menu.

Changing Folders

If you select the option to change folders the Voicemail System will present you with the following options:

- "0" "New" messages.
- "1" "Old" messages.
- "2" "Work" messages.
- "3" "Family" messages.
- "4" "Friends" messages.
- "5" "Folder 5" messages.